

Front Panel

This appendix displays the front panel of all switches covered by this guide.

DCS-7048T-A




Figure D-1: DCS-7048T-A Front Panel

DCS-7050S-64




Figure D-2: DCS-7050S-64 Front Panel

DCS-7124SX




Figure D-3: DCS-7124SX Front Panel