


Rear Panels

This appendix displays the rear panel of all switches covered by this guide.

DCS-7368X4 Rear Panel



- | | | | |
|---|-----------------------------------|----|----------------------------|
| 1 | Switch Card Module Release Handle | 2 | Fan |
| 3 | Fan Module Release Lever | 4 | Fan Installation Indicator |
| 5 | Fan Status LED | 6 | PSU Status LED |
| 7 | PSU | 8 | PSU Release Handle |
| 9 | Ground | 10 | ESD |

